
Electric stove log store assembly instructions

PARTS SUPPLIED



Left leg




Right leg



Left infill panel



Right infill panel



Bottom brace



Screw type A
4 x



Screw type B
4 x




Screw type C
8 x

STEP 1

Hand fit two **type A** screws to the holes on the right side of the stove. Do not fully tighten at this stage.





2 x
Type A



STEP 2

Fit the right leg by locating the keyhole slots over the two **type A** screws and push outwards. Tighten the screws using the **large hex key** supplied.






V190826

GBR IRL NLD BEL FRA ESP DEU ITA

STEP 3

Position the **right infill panel** and secure using four **type C** screws and the **small hex key** supplied.




4 x
Type C




STEP 4

Repeat steps 1-3 on the other side using the **left leg** and **left infill panel**.




STEP 5

Position the **bottom brace** between the **two legs** and secure using four **type B** screws and the **small hex key**.



4 x
Type B



STEP 6

Raise the stove into an upright position and refer to the stove instruction manual for operating instructions.

NOTE

When fitting this log store to the electric stove, the four stove legs that are supplied with the stove are not required and may be discarded.

V190826